

Installation

In-Wall Cabinets™ are surprisingly easy to install which makes for a great evening or weekend DIY project. Create a custom built in look without the cost of custom cabinets. Use just one cabinet or several to create the custom look in any room of your home. In-Wall Cabinets are great for residential and commercial applications.



Every In-Wall Cabinet comes with a tube of Loctite™ Power Grab™ adhesive which is a premium quality, high strength adhesive. "Power Grab eliminates the need for nails or screws by having nine times the initial holding power of any other adhesive on the market."

Door Styles

Door style options:

- A. Plain glass door
- B. Wood frame glass door
- C. Wood frame mirror door
- D. Wood frame decorative leaded glass door
- E. Wood frame w/ matching solid wood panel



Door knobs come standard with all cabinets door styles.



Black Knobs:
Standard with Wine and Fireplace cabinets



Brass Knobs:
Standard with all other cabinets

All Cabinets are available in solid Oak or Maple in
5 popular finishes

Finishes and Options

Unfinished

Natural Finish

Honey Finish

Colonial Finish

Cherry Finish

Dark Mahogany Finish

key lock set:
available for both wood
and solid glass doors



Light Kit:
available for Large or
Medium cabinets.

* Requires professional hard
wire installation

In Wall Cabinets
Recessed Originals

523 N. Fairview St.
Santa Ana, CA 92703
Phone: 714.541.9200 • Fax 714.541.9280
www.inwallcabinets.com